



95 Chanter's Hill, Barnstaple, Devon, EX32 8DG

Tel/Fax: (01271) 379622 - Mobile: (07971) 924074

email: [info@parts4boilers.net](mailto:info@parts4boilers.net) - web: [www.parts4boilers.net](http://www.parts4boilers.net)

Facebook: [www.facebook.com/parts4boilers](http://www.facebook.com/parts4boilers) - Twitter: [@parts4boilers](https://twitter.com/parts4boilers)

*Independent Trade Suppliers of Heating Spares, Controls & Accessories*

---

**MANUFACTURERS PARTS LIST**

**PROTHERM**

---

Part Number	Description
0020023214	El. ignition
0020023215	Fan
0020023216	Pressure sensor HW
0020023217	Pump
0020023219	Printed circuit - display
0020023220	Gas valve
0020023604	Side panel
0020025202	Control board ST6-8
0020025207	Pump UPS15-50/130-AO
0020025212	1-speed fan II
0020025213	Fan
0020025233	Temp. sensor
0020025235	Temp. sensor 1016-to surface
0020025244	Gas valve
0020025245	Air pressure switch
0020025256	Heat exchanger d.h.w. E6N/16
0020025264	Heat exchanger
0020025271	Pressure relief valve 300kPa
0020025277	Hydraulics block - output
0020025293	Printed circuit
0020025294	Heat exchanger d.h.w. E6N/14
0020025297	Heat exchanger - bithermical
0020025298	Expansion vessel - heating 5L
0020025304	Hydraulics block Jaguar - output
0020025305	Printed circuit 24KXVJ
0020025306	Printed circuit 80E TB
0020025307	Printed circuit 80E TC
0020025310	Pump

0020025311	Pump
0020025319	Gas valve
0020027507	Ionisation electrode
0020027534	Diff. pressure switch
0020027537	Thermostat-bim non-revers 95C
0020027542	Air vent 3/8
0020027544	Ball corner valve 3/4
0020027550	Expansion vessel 7L 3/8
0020027569	Microswitch -hydroblock
0020027575	Thermostat bim.non-revers.
0020027585	Seal to tube A,B (PK10)
0020027595	Block KXV15-outlet
0020027596	Ignition electrodes
0020027597	Flow sensor CW
0020027598	Time clock analogue
0020027599	Block-inlet
0020027600	Wire, supply pump
0020027602	Membrane DHW (U 0024)
0020027604	Display board TC
0020027631	Auto ignition control
0020027665	Sealing ring 24x15x2 (PK10)
0020027668	Wire
0020027669	Flow sensor - mechanic.
0020027670	Expansion vessel 7L-3/8
0020033198	Ignition electrode - set
0020033200	Ionisation electrode
0020033233	Mains On/Off switch
0020033329	Ball corner valve 1/2
0020033331	Drain valve 1/4
0020033344	Clip for exchanger
0020033425	Connecting pipe A
0020033426	Connecting pipe B
0020033427	Clip for microswitch
0020033428	Clip for by-pass
0020033429	Clip for tube A,B
0020033433	Seal OR 2050 (PK10)
0020033456	Thermofuse clip II
0020033467	O-Ring 18x3,5 (PK10)
0020033473	Gasket 15x8x2 (PK10)
0020033524	Insulation SK 184x168
0020033584	Insulation SK 300x217
0020033880	Reduction-saf.valve G1/2-3/4
0020033885	Insulation SK 204x340
0020033887	Insulation SK 204x360
0020033921	Limiting pin 70004250
0020033932	Sealing ring, AFM 34 18x10x2 (PK10)
0020034088	Clip - Pump
0020034094	Gasket fan J (PK5)
0020034102	Gas tube J
0020034104	Hose arm. 3/8-3/8-elbow 30cm

0020034105	By-pass tube
0020034114	O-Ring 14x9,5x2,5 (PK10)
0020034120	Clip - Pump
0020034121	Nipple - Pump
0020034122	Pressure sensor clip
0020034123	Pressure sensor reduction
0020034150	Connecting tube A
0020034151	Connecting tube B
0020034155	Wire
0020034631	Wire-set KTVJ
0020034641	Therm.-bim. non-reverse 120C
0020034646	Front cover - turbo 100EC
0020034654	Seal. tape self-stick 5x218x15
0020034655	Seal. tape self-stick 3x488x15
0020034657	Sea. tape self-stick 10x522x15
0020034686	Cover, TURBO E
0020034771	Pipe - Expansion vessel
0020034774	Fan
0020034939	Fuse T 250mA
0020035510	Burner
0020035602	Gasket D20x24x4 (PK5)
0020043215	Heat exchanger 105369
0020043217	O-Ring for exchanger (PK10)
0020043598	Plate heat exchanger E5N/14
0020044964	Gasket (PK10)
0020056493	Time switch
0020094636	Manometer
0020096388	Heat exchanger 3HR (assembly)
0020097207	Sensor flow
0020097214	Diverter valve 3 way
0020097216	Motor pump
0020097220	Motor pump
0020097237	Insulation, side panel
0020097238	Gasket panel
0020097243	Gasket panel
0020097250	Screw (PK10)
0020097252	Gasket (PK5)
0020097253	Gasket (PK10)
0020097255	Plug (PK10)
0020097257	Plug (PK5)
0020097261	Support heat exchanger, kit of 2
0020097262	Support heat exchanger, kit of 2
0020097263	Support heat exchanger, kit of 2
0020097264	Screw (PK10)
0020097268	Pipe - Air inlet
0020097269	Pipe, air inlet
0020097270	Pipe, air inlet
0020097271	Pipe, air inlet
0020097284	Strap (PK5)
0020097285	Plastic control box cover

0020097301	Screw pack (PK75)
0020097302	Plug 2 wires (PK5)
0020097304	Plug 6 wires (PK5)
0020097305	Tube expansion vessel heating
0020097308	Pipe, heat exchanger / 3-way-valve
0020097309	Pipe, heat exchanger / 3-way-valve
0020097310	Pipe, heat exchanger inferior
0020097311	Pipe, gas connection
0020097312	Pipe, gas connection
0020097313	Pipe, gas connection
0020097315	tube
0020097326	Support-plastic lower
0020097327	Support-plastic upper
0020097328	Expansion vessel
0020097329	Flow limiter 10L (PK10)
0020097336	Tap drain piece
0020097340	Siphon assembly
0020097978	Harness, supply
0020098017	Plug
0020098499	Cold water tap
0020098500	Connection, hot water
0020105917	Front panel
0020118629	Gas pipe gasket housing (PK10)
0020118638	Sensor - ntc immersion (-40c to 110c)
0020118640	Diverter Valve Motor 3WV ELBI
0020118643	Spindle white (PK10)
0020118654	O-ring, plate heat exchanger (PK10)
0020118655	Clip - 3 way valve motor pk10
0020118663	Clip (PK10)
0020118708	Nitril gasket (gas pipe)
0020118730	Bottom brass connection 3wv
0020118736	Outlet nipple
0020119266	Black Nut & Spindle Kit for Div Valve
0020119267	Mounting bracket-condensate trap
0020119268	Tapping screw, 3.5x9.5
0020119270	Hexagon nut M3
0020129398	Flexible hose
0020129813	Screw (PK10)
0020129815	Housing of motor pump dcw
0020129827	Washer bag kit
0020129828	Support - Expansion Vessel
0020129830	Drain tap
0020132291	Measuring orifice 6.1mm
0020132292	Measuring orifice 5.8mm
0020132294	Measuring orifice 4.8mm
0020132297	Measuring orifice 7.3mm
0020132431	Installation kit
S230534	Top outlet flue pack
S461215	Front
S461222	Pumped flow pipe

S461223	Flue hood
S461257	Controls cover assembly
S461271	Gravity return pipe
S461275	Pumped flow pipe